



**M 1 : 1**  
zxy-configuration

translators can be combined in various configurations (see example)

Please note! There must be a gap ( $\geq 0,5\text{mm}$ ) between the translators and between the translator and its mounting point too, otherwise the movement will be hindered and the actuator may be destroyed. Use the spacers!

fixing area

**ORIGINAL**

	part.-no.	T-506-00	part.-name	PU 40
	file name	PT50600	OK date/sign	29. APR 2013

scale  
2:1

customers drawing  
*piezosystem jena*

